


THERMALTAKE TECHNOLOGY


525 Parriott Place City of Industry, CA • 1-800-988-1088 • tsupport@thermaltakeusa.com






Connecting the fan.

If the Thermaltake that you have has a 4-Pin Molex connector, please connect it directly to the power supply.



If the Thermaltake fan have you have has a 3-pin Molex connector, please connect it to any available fan connector on the motherboard.



If the Thermaltake fan comes with an *optional* 3-pin Molex connector (that only has a single yellow wire), please connect it to any available fan connector on the motherboard. This single wire connector is usually found on fan that uses a 4-Pin Molex connector which allows the RPM signal to be sent to motherboard.

